



INSTRUCTIONS

**Pro Magnum Lifter™ Instructions for Part #'s
858-12, 858-16, 862-12, 862-16, 863-16, 865-12, 865-16, 867-12, 867-16, 875-12,
875-16, 885-12, 885-16, 887-16**

All Pro Magnum Lifters™ require an adjustable valve train for proper operation. Lifter preload should be set to .002”-.004” (hot settings). These adjustments should be made similar to the adjustment for a hydraulic lifter camshaft.



Competition Cams, Inc
3406 Democrat Rd.
Memphis, TN 38118
(901)795-2400 FAX (901)366-1807
www.compcams.com

Part #160
Revised 6/14/04



INSTRUCTIONS

**Pro Magnum Lifter™ Instructions for Part #'s
858-12, 858-16, 862-12, 862-16, 863-16, 865-12, 865-16, 867-12, and 867-16**

All Pro Magnum Lifters™ require an adjustable valve train for proper operation. Lifter preload should be set to .002”-.004” (hot settings). These adjustments should be made similar to the adjustment for a hydraulic lifter camshaft.



Competition Cams, Inc
3406 Democrat Rd.
Memphis, TN 38118
(901)795-2400 FAX (901)366-1807
www.compcams.com

Part #160
Revised 6/14/04

