How to use:

1. Drain all the water in the tank;

2. Open the hood of the car and hang the hook in place;

3. Connect the universal rubber joint to the water tank or select the appropriate joint to connect to the water tank;

4. Make sure all the switches are turned off and connect the thin tube and the connector on the tail of the mouse to the water tank;

5. Connect the air intake pipe, turn on the air intake switch, and connect the vacuum pump for vacuuming. When the pressure reaches a 20~-25lnhg (-50~-60cmhg), turn off the No. 3 switch;

6. Attach the antifreeze hose to the main body of the meter and place the other end in the antifreeze container. The interface must be completely submerged below the water level. Turn on the water inlet switch to automatically replenish the antifreeze into the tank.